

L-1 SYNTH

VC Stereo Mixer. Trimming.

Gain


OUT, 1, 2, 3, 4 trimots set the levels of each channel and the out level.

Set all levels to max, all panoramas to left. Split 1kHz sine into two. Connect first to one channel of analyzer or oscilloscope, second to IN1. Connect second channel of analyzer to OUT LEFT. Adjust 1 and OUT trimpots to have levels equal.


Then connect sine to IN2, set 2 trimpot to have levels equal.

Repeat for remaining channels.

Before



After



Download free Signal Analyzer here <http://rs-met.com/freebies.html>